Symptom:

P0443-EVAP PURGE SOLENOID CIRCUIT

When Monitored and Set Condition:

P0443-EVAP PURGE SOLENOID CIRCUIT

When Monitored: The ignition on or engine running. Battery voltage greater than 10 volts.

Set Condition: The PCM will set a trouble code if the actual state of the solenoid does not match the intended state.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
EVAP PURGE SOLENOID
(K52) EVAP PURGE SOL CONTROL CIRCUIT OPEN
(K52) EVAP PURGE SOL CONTROL CIRCUIT SHORTED TO GROUND
(K70) EVAP PURGE SOL SIGNAL CIRCUIT OPEN
(K70) EVAP PURGE SOL SIGNAL CIRCUIT SHORTED TO GROUND
(K70) EVAP PURGE SOL SIGNAL CIRCUIT SHORTED TO BATTERY VOLTAGE
PCM

TEST	ACTION	APPLICABILITY
1	Check for any related TSBs before continuing. Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the EVAP Purge Solenoid harness connector. Ignition on, engine not running. Using a 12-volt test light, jump across the (K52) Evap Purge Sol Control circuit and (K70) Evap Purge Sol Signal circuit in the EVAP Purge Solenoid harness connector. With the DRBIII®, actuate the EVAP Purge Solenoid. Does the test light flash on and off? Yes → Replace the EVAP Purge Solenoid. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 3	All