P0452-NVLD PRESSURE SWITCH STUCK CLOSED — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. Connect the Evap Purge Solenoid harness connector. Disconnect the vacuum hoses at the Evap Purge Solenoid. **NOTE: After disconnecting the Evap Purge Solenoid vacuum connections, inspect the lines and solenoid for any signs of contamination from the EVAP Canister. This may indicate a faulty rollover valve. Replace/repair as necessary.** Using a hand vacuum pump, apply 10 in Hg to the ″CAN″ of the EVAP Purge Solenoid. **NOTE: Monitor the vacuum gauge for at least 15 seconds.** Does the EVAP Purge Solenoid hold vacuum? Yes → Go To 4 No → Replace the Evap Purge Solenoid. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
4	Ignition on, engine not running. Using the DRBIII®, monitor the NVLD Switch State with the vacuum pump still installed and holding vacuum. Does the DRBIII® display the NVLD state OPEN? Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 5 **NOTE: Remove the vacuum pump and connect the vacuum hose before continuing.**	All
5	Disconnect the NVLD electrical connector. Does the Switch change from CLOSED to OPEN? Yes → Replace the NVLD Assembly. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 6	All
6	Turn the ignition off. Disconnect the C3 PCM harness connector. Measure the resistance between ground and the (K107) NVLD Switch Signal circuit in the NVLD Assembly harness connector. Is the resistance below 5.0 ohms? Yes → Repair the short to ground in the (K107) NVLD Switch Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 8	All
7	Turn the ignition off. Disconnect the C3 PCM harness connector. Measure the resistance between ground and the (K52) Evap Purge Sol Control circuit at the EVAP Purge Solenoid harness connector. Is the resistance below 5.0 ohms? Yes → Repair the short to ground in the (K52) Evap Purge Sol Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 8	All