Symptom:

P0453-NVLD PRESSURE SWITCH STUCK OPEN

When Monitored and Set Condition:

P0453-NVLD PRESSURE SWITCH STUCK OPEN

When Monitored: Engine running.

Set Condition: If the PCM does not see the NVLD switch close during test an error is detected. One Trip Fault.

POSSIBLE CAUSES
NVLD SWITCH OPERATION
NVLD ASSEMBLY
(K107) NVLD SWITCH SIGNAL CIRCUIT SHORTED TO BATTERY VOLTAGE
(K107) NVLD SWITCH SIGNAL CIRCUIT OPEN
(K107) NVLD SWITCH SIGNAL CIRCUIT SHORTED TO THE (K106) SOLENOID CONTROL CIRCUIT
(Z913) GROUND CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	Check for any related TSBs before continuing. Start the engine. Allow the engine to idle. Using the DRBIII®, perform the NVLD FORCED MONITOR TEST. Monitor the NVLD Switch state. **NOTE: As the test runs, the NVLD Switch should go from an OPEN state to a CLOSED state and then return to OPEN when the test is complete.** Did the NVLD Switch operate as described above? Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 2	All
2	Turn the ignition off. Disconnect the NVLD electrical harness connector. Ignition on, engine not running. Monitor the NVLD Switch state on the DRBIII®. Connect a jumper wire between the (K107) NVLD Switch Signal circuit and the (Z913) Ground circuit in the NVLD harness connector. Does the Switch change from OPEN to CLOSED? Yes → Replace the NVLD Assembly. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 3 **NOTE: Remove the jumper wire before continuing.**	All