P0457-LOOSE FUEL FILL CAP — Continued

TEST	ACTION	APPLICABILITY
2	Perform a visual and physical inspection of the Fuel Fill Cap and the fill tube. Check for the follow conditions: - Improper installation of Fuel Fill Cap - Loose or missing Fuel Filler Cap - Holes or cracks - Damaged Locking tabs on Cap and/or fill tube - Damaged seal points on Cap and/or fill tube - Fuel Fill Cap gasket seal Were any of the above conditions found? Yes → Repair or replace the fuel fill cap as needed. Ensure proper fuel fill cap installation. Once the repair is complete continue to step 3. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 3	All
3	With the DRBIII®, perform the NVLD Service Test. Did the NVLD Service Test pass? Yes → Test Complete. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 4	All