Symptom:

P0461-FUEL LEVEL SENSOR NO.1 PERFORMANCE

When Monitored and Set Condition:

P0461-FUEL LEVEL SENSOR NO.1 PERFORMANCE

When Monitored: TEST #1: With the ignition on, the fuel level is compared to the previous key down after a 20 second delay. TEST #2: The PCM monitors the fuel level at ignition on.

Set Condition: TEST #1: If the PCM does not see a difference in fuel level of greater than 0.1 volt the test will fail. TEST #2: If the PCM does not see a change in the fuel level of .1765 over a set amount of miles the test will fail.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
VISUALLY INSPECT FUEL TANK
(N4) FUEL LEVEL SIGNAL CIRCUIT OPEN
(N4) FUEL LEVEL SIGNAL CIRCUIT SHORTED TO GROUND
(K900) SENSOR GROUND CIRCUIT OPEN
INTERNAL INSPECTION OF THE FUEL TANK
FUEL LEVEL SENSOR

TEST	ACTION	APPLICABILITY
1	**NOTE: Diagnose P0462 or P0463 first, if set along with P0461.** **NOTE: Inspect the Fuel Pump Module harness connector for any corrosion or damage.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Visually inspect the Fuel Tank for damage that may restrict the Fuel Sending Unit float from moving. Is the Fuel Tank OK? Yes → Go To 3 No → Replace the Fuel Tank as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All