Symptom:

P0462-FUEL LEVEL SENSOR NO.1 LOW

When Monitored and Set Condition:

P0462-FUEL LEVEL SENSOR NO.1 LOW

When Monitored: Ignition on and battery voltage above 10.4 volts.

Set Condition: The fuel level sensor signal voltage goes below 0.0196 of a volt for more than 90 seconds.

POSSIBLE CAUSES
FUEL LEVEL SENSOR VOLTAGE BELOW 0.0196 OF A VOLT
FUEL LEVEL SENSOR
(N4) FUEL LEVEL SIGNAL CIRCUIT SHORTED TO GROUND
(N4) FUEL LEVEL SIGNAL CIRCUIT SHORTED TO THE (K900) SENSOR GROUND CIRCUIT
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. With the DRBIII®, read the Fuel Level Sensor voltage. Is the Fuel Level Sensor voltage below 0.0196 of a volt? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the Fuel Pump Module harness connector. Ignition on, engine not running. With the DRBIII®, read the Fuel Level Sensor voltage. Did the Fuel Level Sensor voltage change from below 0.4 of a volt to above 4.0 volts? Yes → Replace the Fuel Level Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 3	All
3	Turn the ignition off. Disconnect the C2 and C3 PCM harness connectors. Measure the resistance between ground and the (N4) Fuel Level Signal circuit at the Fuel Level Sensor harness connector. Is the resistance below 100 ohms? Yes → Repair the short to ground in the (N4) Fuel Level Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 4	All