## P0462-FUEL LEVEL SENSOR NO.1 LOW — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 4 | Measure the resistance between the (N4) Fuel Level Signal circuit and the (K900) Sensor ground circuit at the Fuel Pump Module harness connector.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Repair the short between the (K900) Sensor ground and the (N4) Fuel Level Signal circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>No → Go To 5 | All |
| 5 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |