Symptom:

P0508-IAC VALVE SIGNAL CIRCUIT LOW

When Monitored and Set Condition:

P0508-IAC VALVE SIGNAL CIRCUIT LOW

When Monitored: Engine running. Battery voltage greater than 10 volts. IAC motor operating.

Set Condition: The PCM senses a short to ground or battery voltage on the Linear Idle Air Control (LIAC) control circuit for 2.75 seconds while the IAC motor is active.

POSSIBLE CAUSES
IAC MOTOR OPERATTION
IAC MOTOR
(K61) IAC CONTROL CIRCUIT SHORTED TO GROUND
(K961) IAC SIGNAL CIRCUIT OPEN
(K961) IAC SIGNAL CIRCUIT SHORTED TO GROUND
(K61) IAC CONTROL CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	**NOTE: If the engine will not idle, maintain an engine speed between 800 and 1500 RPM.** Start the engine. Allow the engine to idle. Check for vacuum leaks, proper PCV valve installation, proper MAP Sensor installation, and proper IAC installation. With the DRBIII®, read the IAC Current. Is the IAC Current below 146 mA? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the IAC Motor harness connector. Remove the IAC Motor. **NOTE: Inspect the IAC air passages for restriction and damage to the IAC valve.** Measure the resistance across the IAC Motor pin terminals (component). Is the resistance 9.7 +/- 1.0 ohms? Yes → Go To 3 No → Replace the IAC Motor. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All