Symptom:

P0517-BATTERY TEMPERATURE SENSOR HIGH

When Monitored and Set Condition:

P0517-BATTERY TEMPERATURE SENSOR HIGH

When Monitored: Ignition on.

Set Condition: Battery temperature voltage goes above 4.9412 volts for more than 4.8 seconds. Three good trips to clear the MIL.

POSSIBLE CAUSES
BATTERY TEMP SENSOR VOLTAGE ABOVE 4.9412 VOLTS
BATTERY TEMPERATURE SENSOR
(K118) BATT TEMP SIGNAL CIRCUIT SHORTED TO BATTERY VOLTAGE
(K25) BATT TEMP SIGNAL CIRCUIT OPEN
(K900) SENSOR GROUND CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. Record all DTCs and the related Freeze Frame data. With the DRBIII®, monitor the Battery Temperature Sensor voltage. Is the voltage above 4.9412 volts? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
2	Turn the ignition off. Disconnect the Battery Temperature Sensor harness connector. Ignition on, engine not running. With the DRBIII® in sensors, read the Battery Temp Voltage value. Connect a jumper wire between the (K25) Batt Temp Signal circuit and the (K900) Sensor ground circuit at the Battery Temp Sensor harness connector. Did the Battery Temp voltage value change from greater than 4.5 volts to less than 1.0 volt? Yes → Replace the Battery Temperature Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Go To 3 **NOTE: Remove the jumper wire before continuing.**	All