## P0532-A/C PRESSURE SENSOR LOW — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 4 | Turn the ignition off.<br>Disconnect the C3 PCM harness connector.<br>Measure the resistance between ground and the (C18) A/C Pressure Signal circuit in the A/C Pressure Sensor harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the (C18) A/C Pressure Signal circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2.<br><br>No → Go To 5 | All |
| 5 | Measure the resistance between the (C18) A/C Pressure Signal circuit and the (K900) Sensor ground circuit in the A/C Pressure Sensor harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short between the (K900) Sensor ground circuit and the (C18) A/C Pressure Signal circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2.<br><br>No → Go To 8 | All |
| 6 | Turn the ignition off.<br>Disconnect the C1 and C3 PCM harness connectors.<br>**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.**<br>Measure the resistance of the (F856) 5-volt Supply circuit from the A/C Pressure Sensor harness connector to the appropriate terminal of special tool #8815.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Go To 7<br><br>No → Repair the open in the (F856) 5-volt Supply circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |
| 7 | Measure the resistance between ground and the (F855) 5-volt Supply circuit in the A/C Pressure Sensor harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the (F856) 5-volt Supply circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2.<br><br>No → Go To 8 | All |
| 8 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |