## P0582-SPEED CONTROL VACUUM SOLENOID CIRCUIT — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 7 | Turn the ignition off.<br>Disconnect the S/C Servo harness connector.<br>Disconnect the C3 PCM harness connector.<br>Measure the resistance between ground and the (V36) S/C Vacuum Solenoid Control circuit at the Speed Control Servo harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the (V36) S/C Vacuum Sol Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 4.<br><br>No → Go To 10 | All |
| 8 | Turn the ignition off.<br>Disconnect the Brake Lamp Switch harness connector.<br>Disconnect the C3 PCM harness connector.<br>**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.**<br>Measure the resistance of the (V32) S/C Supply circuit from the Brake Lamp Switch harness connector to the appropriate terminal of special tool # 8815.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Go To 9<br><br>No → Repair the open/high resistance in the (V32) S/C Supply circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 4. | All |
| 9 | Turn the ignition off.<br>Disconnect the Brake Switch harness connector.<br>Disconnect the C3 PCM harness connector.<br>Measure the resistance between ground and the (V32) S/C Supply circuit at the Speed Control Servo harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the (V32) S/C Supply circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 4.<br><br>No → Go To 10 | All |
| 10 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>If the there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module in accordance with the Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 4. | All |