Symptom:

P0586-SPEED CONTROL VENT SOLENOID CIRCUIT

When Monitored and Set Condition:

P0586-SPEED CONTROL VENT SOLENOID CIRCUIT

When Monitored: Engine running, the speed control switched on and learned, and the brake pedal is not pressed. No other fault has occured this trip.

Set Condition: The PCM detects an open or short to ground in the Speed Control Vent Control circuit. Cruise will be disabled for the remainder of that key-on cycle. One Trip Fault. Three good trips to clear the MIL.

POSSIBLE CAUSES
SPEED CONTROL SOLENOID OPERATION
(V32) S/C SUPPLY CIRCUIT
SPEED CONTROL VENT SOLENOID
(V32) S/C SUPPLY SHORT TO GROUND
(V35) S/C VENT SOL CONTROL CIRCUIT OPEN
(V35) S/C VENT SOL CONTROL CIRCUIT SHORTED TO GROUND
(V32) S/C SUPPLY CIRCUIT OPEN
(Z901) S/C GROUND CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. With the DRBIII®, actuate the Speed Control Vent Solenoid and note operation. Does the Speed Control Vent Solenoid acutate properly? Yes → Refer to the INTERMITTENT CONDITION symptom in the Driveability category. Perform POWERTRAIN VERIFICATION TEST VER - 4. No → Go To 2	All
2	Turn the ignition off. Disconnect the S/C Servo harness connector. Turn the ignition on. Using the DRBIII®, actuate the S/C Vent Solenoid. Using a test light connected to ground, probe the (V30) S/C Brake Switch Output circuit in the S/C Servo harness connector. Does the test light illuminate brightly and flash on and off? Yes → Go To 5 No → Go To 3	All