## P0645-A/C CLUTCH RELAY CIRCUIT — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 3 | Turn the ignition off.<br>Using a 12-volt test light connected to ground, probe the (A926) Fused B+ circuit of the fuel pump relay in the PDC.<br>Does the test light illuminate brightly?<br><br>Yes → Go To 4<br><br>No → Repair the open or short to ground in the (A926) Fused B+ circuit. Inspect and replace any open fuses.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |
| 4 | Turn the ignition off.<br>Measure the resistance of the A/C Clutch Relay Coil.<br>Is the resistance between 60 to 80 ohms?<br><br>Yes → Go To 5<br><br>No → Replace the A/C Clutch Relay.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |
| 5 | Disconnect the C3 PCM harness connector.<br>**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.**<br>Measure the resistance of the (C13) A/C Clutch Relay Control circuit from the PDC to the appropriate terminal of special tool #8815.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Go To 6<br><br>No → Repair the open in the (C13) A/C Clutch Relay Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |
| 6 | Measure the resistance between ground and the (C13) A/C Clutch Relay Control circuit in the PDC.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Repair the short to ground in the (C13) A/C Clutch Relay Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2.<br><br>No → Go To 7 | All |
| 7 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 2. | All |