## Symptom:

## P0685-ASD RELAY CONTROL CIRCUIT

**When Monitored and Set Condition:**

**P0685-ASD RELAY CONTROL CIRCUIT**

When Monitored: With ignition on. Battery voltage above 10 volts.

Set Condition: An open or shorted condition is detected in the ASD relay control circuit for more than 2.7 seconds. ASD Relay state does not equal the desired state. P0688 will set along with P0685.

| POSSIBLE CAUSES |
|---|
| ASD RELAY OPERATION |
| (A209) FUSED B+ CIRCUITS |
| ASD RELAY |
| (K342) ASD RELAY CONTROL CIRCUIT OPEN |
| (K342) ASD RELAY CONTROL CIRCUIT SHORTED TO GROUND |
| PCM |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Ignition on, engine not running.<br>With the DRBIII®, actuate the ASD Relay.<br>Is the ASD Relay operating?<br>Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure).<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 2 | All |
| 2 | Turn the ignition off.<br>Remove the ASD Relay from the PDC.<br>Using a 12-volt test light connect to ground, probe the (A209) Fused B+ circuits in the PDC.<br>Does the test light illuminate brightly?<br>Yes → Go To 3<br>No → Repair the open or short to ground in the (A209) Fused B+ circuits. Inspect and replace any open fuses.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 3 | Measure the resistance of the ASD Relay Coil.<br>Is the resistance between 60 to 80 ohms?<br>Yes → Go To 4<br>No → Replace the ASD Relay.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |