## P0688-ASD RELAY SENSE CIRCUIT LOW — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 7 | Measure the resistance between ground and the (K334) ASD Relay Output circuit at the Relay connection.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the (K334) ASD Relay Output circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>No → Go To 8 | All |
| 8 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |