Symptom:

P1115-GENERAL TEMPERATURE SENSOR PERFORMANCE

When Monitored and Set Condition:

P1115-GENERAL TEMPERATURE SENSOR PERFORMANCE

When Monitored: With the ignition on and engine running.

Set Condition: The PCM compares the ouputs of the ECT, IAT, and Ambient Temp sensors. If one sensor does not corralate with the other two sensors the fault is set.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
TEMPERATURE SENSOR CIRCUT
FAULTY SENSOR
EXCESSIVE RESISTANCE IN THE SENSOR SIGNAL CIRCUIT
EXCESSIVE RESISTANCE IN THE (K900) SENSOR GROUND CIRCUIT
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, read the DTCs and record the related Freeze Frame data. **NOTE: All ECT, Intake Air, and Ambient Air Temperature Sensor codes must be diagnosed and repaired before continuing.** Is the Good Trip Counter displayed and equal to zero Yes → Go To 2 No → Refer to the INTERMITENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	With the DRBIII® in Sensors, read the ECT, Ambient/Battery Temp, and Intake Air Temp Sensor temp values. Start the engine. Allow the engine to reach normal operating temperature while monitoring the three Sensor temperature values. Is the temperature for each of the Sensors increasing properly? Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 3	All