Symptom:
*CHECKING PCM POWERS AND GROUNDS

POSSIBLE CAUSES
(A209) PCM FUSED B+ CIRCUIT
(F1) AND (F26) PCM FUSED IGNITION SWITCH OUTPUT CIRCUITS
(Z130) (Z131) PCM GROUND CIRCUITS

TEST	ACTION	APPLICABILITY
1	Turn the ignition off. Disconnect the C1 PCM harness connector. **CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** Using a 12-volt test light connected to ground, probe the (A209) PCM Fused B+ circuit in the appropriate terminal of special tool #8815. Does the test light illuminate brightly? Yes → Go To 2 No → Repair the open in the (A209) Fused B+ circuit. Inspect the related fuses and repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
2	**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** Ignition on, engine not running. Using a 12-volt test light connected to ground, probe the (F1) and (F26) PCM Fused Ignition Switch Output (Off, Run, Start) circuits in the appropriate terminals of special tool #8815. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the open in the (F1) or (F26) Fused Ignition Switch Output (Off, Run, Start) circuit(s). Inspect the related fuses and and repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
3	Turn the ignition off. **CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** Using a 12-volt test light connected to battery voltage, probe the (Z130) and (Z131) PCM Ground circuits in the appropriate terminals of special tool #8815. Does the test light illuminate brightly? Yes → Test Complete. No → Repair the open in the (Z130) and (Z131) PCM Ground circuit(s). Perform POWERTRAIN VERIFICATION TEST VER - 1.	All