*CHECKING HARD START (FUEL DELIVERY SYSTEM) — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. **WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose,fitting or line, the fuel system pressure must be released.** Remove the Fuel Pump Module and inspect the Fuel Inlet Strainer. Is the Fuel Inlet Strainer plugged? Yes → Replace the Fuel Pump Inlet Strainer. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Test Complete.	All
4	**NOTE: Before continuing visually and physically inspect the fuel delivery system for external leaks or damage. Repair /replace as necessary.** Turn the ignition off. **WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Install special tool #6539 (5/16″) fuel line adapter. Install the fuel pressure gauge. Start the engine and allow the fuel system to reach maximum pressure. Turn the ignition off. **NOTE: Fuel specification is 400 KPa +/- 34 KPa (58 psi +/- 5 psi).** Using special tool #C4390, Hose Clamp Pliers, pinch the rubber fuel line between the fuel pressure gauge and the engine. Monitor the fuel pressure gauge for a minimum of 5 minutes. **NOTE: The pressure should not fall below 241 KPa (35 psi)** Does the fuel pressure drop? Yes → Replace fuel pump module. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Go To 5	All
5	**WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Remove special tool #C4390. Start the engine and allow the fuel system to reach maximum pressure. Turn the ignition off. **NOTE: Fuel specification is 400 KPa +/- 34 KPa (58 psi +/- 5 psi).** Install special tool #C4390, Hose Clamp Pliers, pinch the rubber fuel line between the fuel pressure gauge and the fuel pump module. Monitor the fuel pressure gauge for a minimum of 5 minutes. **NOTE: The pressure should not fall below 241 KPa (35 psi)** Does the fuel pressure drop? Yes → Replace leaking fuel injectors. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Check the fuel for contaminants. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All