Symptom:
*ENGINE CRANKS DOES NOT START

POSSIBLE CAUSES
NO START PRE-TEST
POWERTRAIN FUSES OPEN
SECONDARY INDICATORS PRESENT
NO CKP SENSOR SIGNAL WHEN CRANKING ENGINE
NO CMP SENSOR SIGNAL WHEN CRANKING ENGINE
ENGINE MECHANICAL PROBLEM
(A142) ASD RELAY OUTPUT CIRCUIT OPEN
FUEL CONTAMINATION

TEST	ACTION	APPLICABILITY
1	**Note: The following list of items must be checked before continuing with any no start tests.** The battery must be fully charged and in good condition. A low charged battery may produce invalid test results. If the battery is low, charge the battery and then attempt to start the vehicle by cranking the engine for 15 seconds, 3 consecutive times. This will allow any DTCs to set that may have been erased due to a dead battery. Try to communicate with PCM, if not able to communicate check fuses. Make sure the Powers and Ground to the PCM are ok. Make sure the PCM communicates with the DRBIII® and that there are no DTCs stored in the PCM memory. If the PCM reports a No Response condition, refer to the Communication category for the proper tests. Read the PCM DTCs with the DRBIII®. If any DTCs are present, they must be repaired before continuing with any other No Start diagnostic tests. Refer to the Symptom list for the related P-code that is reported by the PCM. Make sure that the PCI bus is functional. Attempt to communicate with the Instrument Cluster and VTSS. If you are unable to establish communicate refer to the Communication category for the proper symptoms. The Sentry Key Immobilizer System must be operating properly. Check for proper communication with the DRBIII® and check for DTCs that may be stored in the Sentry Key Immobilizer Module (SKIM). Repair the DTC(s) before continuing. If no DTCs are found, using the DRBIII®, select Clear PCM (BATT Disconnect). Crank the engine several times. Using the DRBIII®, read DTCs. If a DTC is present perform the DTC diagnostics before continuing. Were any problems found? Yes → Repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 2	All
2	Check for any open fuses in the PDC or Junction Block that may be related to the No Start condition. Are any of the fuses open? Yes → Replace the open fuse and check the related circuit(s) for a short to ground. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 3	All