Symptom:
*NO CRANK CONDITION

POSSIBLE CAUSES
MECHANICAL CONDITION
TRANSMISSION RANGE SENSOR
BATTERY CIRCUIT RESISTANCE TOO HIGH
CLUTCH PEDAL POSITION SWITCH
(T141) FUSED IGNITION SWITCH OUTPUT CIRCUIT OPEN
TRS T41 SENSE (P/N SENSE) CIRCUIT OPEN
(T40) STARTER RELAY OUTPUT CIRCUIT OPEN
(A2) FUSED B+ CIRCUIT OPEN
STARTER
STARTER RELAY

TEST	ACTION	APPLICABILITY
1	**NOTE: Check all fuses and verify the battery is fully charged and capable of passing a load test before continuing.** **WARNING: MAKE SURE THE BATTERY IS DISCONNECTED, THEN WAIT TWO MINUTES BEFORE PROCEEDING.** Turn the engine over by hand to ensure the engine is not seized. Is the engine able to turn over? Yes → Go To 2 No → Repair the mechanical condition preventing the starter motor from cranking. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
2	Turn the ignition off. Disconnect the PCM harness connectors. Move the Gear selector through all gear positions, from Park to 1st and back. While moving the gear selector through each gear, measure the resistance between ground and the TRS T41 Sense (P/N Sense) circuit. Did the resistance change from above 10.0 ohms to below 10.0 ohms? Yes → Go To 3 No → Replace the Transmission Range Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
3	Check the Battery Cables for high resistance using the service information procedure. Did either Battery Cable have a voltage drop greater than 0.2 of a volt? Yes → Repair the Battery circuit for high resistance. Perform POWERTRAIN VERIFICATION TEST VER - 1. No → Go To 4	All