Symptom:

***NO RESPONSE FROM PCM WITH A NO START CONDITION**

POSSIBLE CAUSES
PCM FUSED B+ CIRCUIT
PCM NO RESPONCE
PCM FUSED IGNITION SWITCH OUTPUT CIRCUIT
PCM GROUND CIRCUITS
TP SENSOR
5-VOLT SENSOR OPEN OR SHORTED
(K7) 5-VOLT SUPPLY CKT SHORT TO GROUND
(K6) 5-VOLT CIRCUIT SUPPLY SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	**NOTE: The DRBIII® and cable must be operating properly for the results of this test to be valid.** **NOTE: Ensure the ignition switch was on while trying to communicate with the PCM.** Turn the ignition off. Disconnect the PCM harness connectors. Using a 12-volt test light connected to ground, backprobe the PCM Fused B+ circuit in the PCM harness connector. Does the test light illuminate brightly? Yes → Go To 2 No → Repair the open in the Fused B+ circuit. Inspect and replace fuses as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
2	Ignition on, engine not running. Using a 12-volt test light connected to ground, backprobe the PCM Fused Ignition Switch Output circuit in the PCM harness connector. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the open in the Ignition Switch Output circuit. Inspect and replace fuses as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
3	Turn the ignition off. Using a 12-volt test light connected to 12-volts, backprobe the PCM ground circuits in the PCM harness connector. Does the test light illuminate brightly? Yes → Go To 4 No → Repair the opens in the PCM ground circuits. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All