## Symptom:
## *START AND STALL CONDITION

| POSSIBLE CAUSES |
|---|
| CHECKING DTCS |
| CHECKING SKIM DTCS |
| TP SENSOR SWEEP |
| TP SENSOR VOLTAGE GREATER THAN 0.92 VOLTS WITH THROTTLE CLOSED |
| ECT SENSOR OPERATION |
| OTHER POSSIBLE CAUSES FOR START & STALL |
| FUEL CONTAMINATION |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Ignition on, engine not running.<br>With the DRBIII®, read engine DTCs.<br>Are any DTCs present?<br>Yes → Refer to the Driveability Category and perform the appropriate symptom.<br>Perform POWERTRAIN VERIFICATION TEST VER - 1.<br>No → Go To 2 | All |
| 2 | **NOTE: If you are unable to communicate with the SKIM, refer to the Communication Category and perform the appropriate symptom.**<br>With the DRBIII®, read the SKIM codes.<br>Are there any SKIM DTCs?<br>Yes → Refer to the Vehicle Theft category and perform the appropriate symptom.<br>Perform POWERTRAIN VERIFICATION TEST VER - 1.<br>No → Go To 3 | All |
| 3 | With the DRBIII®, read TP Sensor voltage.<br>While monitoring the DRBIII®, slowly open and close the Throttle.<br>Is the voltage change smooth?<br>Yes → Go To 4<br>No → Replace the Throttle Position Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 1. | All |
| 4 | With the DRBIII®, read TP Sensor voltage. Throttle must be against stop.<br>Is the voltage 0.92 or less with the Throttle closed?<br>Yes → Go To 5<br>No → Check for a binding throttle condition. If OK, replace the Throttle Position Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 1. | All |