## P0750-LR SOLENOID CIRCUIT — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 7 | Turn the ignition off to the lock position.<br>Disconnect the TCM harness connector.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Measure the resistance between ground and the L/R Solenoid Control circuit.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Repair the L/R Solenoid Control circuit for a short to ground. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Go To 8 | All |
| 8 | Turn the ignition off to the lock position.<br>Disconnect the TCM harness connector.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Remove the Transmission Control Relay from the PDC.<br>**Note: Check connectors - Clean/repair as necessary.**<br>Connect a jumper wire between the Fused B+ circuit and the Transmission Control Relay Output circuit in the Transmission Control Relay connector in the PDC.<br>Ignition on, engine not running.<br>Measure the voltage of the L/R Solenoid Control circuit.<br>Is the voltage above 0.5 volt?<br><br>Yes → Repair the L/R Solenoid Control circuit for a short to voltage. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Go To 9 | All |
| 9 | Turn the ignition off to the lock position.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Remove the Transmission Control Relay from the PDC.<br>**Note: Check connectors - Clean/repair as necessary.**<br>Connect a jumper wire between the Fused B+ circuit and the Transmission Control Relay Output circuit in the Transmission Control Relay connector in the PDC.<br>Ignition on, engine not running.<br>Using a 12-volt test light connected to ground, check the Transmission Control Relay Output circuit.<br>**NOTE: The test light must illuminate brightly. Compare the brightness to that of a direct connection to the battery.**<br>Does the test light illuminate brightly?<br><br>Yes → Go To 10<br><br>No → Repair the Transmission Control Relay Output circuit for an open or high resistance. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. | All |
| 10 | Using the schematics as a guide, inspect the wiring and connectors. Repair as necessary. Pay particular attention to all power and ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace the Transmission Control Module per the Service Information. WITH THE DRBIII® PERFORM QUICK LEARN. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. | All |