## Verification Tests

| 42RLE TRANSMISSION VERIFICATION TEST - VER 1 | APPLICABILITY |
|---|---|
| 1. Connect the DRBIII® to the Data Link Connector (DLC).<br>2. Reconnect any disconnected components.<br>3. With the DRBIII®, erase all Transmission DTC's, also erase the PCM DTC's.<br>**4. NOTE: Erase DTC P0700 in the PCM to turn the Malfunction Indicator Lamp (MIL) off after making Transmission repairs.**<br>5. With the DRBIII®, display Transmission Temperature. Start and run the engine until the Transmission Temperature is HOT - above 43° C or 110° F.<br>6. Check the Transmission Fluid and adjust if necessary. Refer to the Service information for the Fluid Fill procedure.<br>**7. NOTE: If the Transmission Control Module or the Transmission has been repaired or replaced it is necessary to perform the DRBIII® Quick Learn Procedure and reset the "Pinion Factor"**<br>8. Road test the vehicle. With the DRBIII®, monitor the engine RPM. Make 15 to 20 1-2, 2-3, 3-4 upshifts. Perform these shifts from a standing start to 45 MPH with a constant throttle opening of 20 to 25 degrees.<br>9. Below 25 MPH, make 5 to 8 wide open throttle kickdowns to 1st gear. Allow at least 5 seconds each in 2nd and 3rd gear between each kickdown.<br>10. For a specific DTC, drive the vehicle to the Symptom's When Monitored/When Set conditions to verify the DTC repair.<br>11. If equipped with AutoStick®, up-shift and down-shift several times using the AutoStick® feature during the road test.<br>**12. NOTE: Use the EATX OBDII Task Manager to run Good Trip time in each gear, this will confirm the repair and to ensure that the DTC has not re-matured.**<br>13. Check for Diagnostic Trouble Codes (DTC's) during the road test. If a DTC sets during the road test , return to the Symptom list and perform the appropriate Symptom.<br>Were there any Diagnostic Trouble Codes (DTCs) set during the road test?<br>Yes → Refer to the Symptom List for appropriate Symptom(s).<br>No → Repair is complete. | All |

| BODY VERIFICATION TEST - VER 1 | APPLICABILITY |
|---|---|
| 1. Disconnect all jumper wires and reconnect all previously disconnected components and connectors.<br>**2. NOTE: If the SKIM or PCM was replaced, refer to the service information for proper programming procedures.**<br>**3. NOTE: If the MIC was replaced, configure new cluster with Tire Size, Axle, T-Case Type, and EQ Setting.**<br>4. Ensure all accessories are turned off and the battery is fully charged.<br>5. With the DRBIII®, record and erase all DTC's from ALL modules. Start and run the engine for 2 minutes. Operate all functions of the system that caused the original concern.<br>6. Turn the ignition off and wait 5 seconds. Turn the ignition on and using the DRBIII®, read DTC's from ALL modules.<br>Are any DTCs present or is the original condition still present?<br>Yes → Repair is not complete, refer to the appropriate symptom.<br>No → Repair is complete. | All |