MAINTENANCE SCHEDULES (Continued)

Kilometers **(Miles)** **[Months]**	**58 000** **(36,000)** **[36]**	**67 000** **(42,000)** **[42]**	**77 000** **(48,000)** **[48]**	**86 000** **(54, 000)** **[54]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Inspect the brake linings.	X			X

Kilometers **(Miles)** **[Months]**	**96 000** **(60,000)** **[60]**	**106 000** **(66,000)** **[66]**	**115 000** **(72,000)** **[72]**	**125 000** **(78,000)** **[78]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Inspect the engine air filter element, and replace if necessary.	X			
Inspect the PCV Valve, and replace if necessary. ◇	X			
Replace the ignition cables (2.4L Only).	X			
Replace the spark plugs.	X			
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Inspect the brake linings.			X	
Inspect the drive belt, and replace as needed.	X			
Inspect the drive belt, and replace as needed. Not required if belt was previously replaced.			X	
Flush and replace the engine coolant/anti-freeze at 60 months, if not done at 163 000 km (102,000 miles).	X			
Inspect transfer case fluid.	X			