FRONT

TABLE OF CONTENTS

page

FRONT
DESCRIPTION 6
STANDARD PROCEDURE - LUBRICATION 6
SPECIFICATIONS
TORQUE CHART 7
SPECIAL TOOLS
FRONT SUSPENSION 7
BUSHINGS
REMOVAL 8
INSTALLATION 8
HUB / BEARING
DESCRIPTION 8
OPERATION 9
REMOVAL 9
INSTALLATION 9
JOUNCE BUMPER
DESCRIPTION 10
KNUCKLE
REMOVAL 10
INSTALLATION 10
LOWER BALL JOINT
REMOVAL 10
LOWER CONTROL ARM
DESCRIPTION 11
OPERATION 11
REMOVAL 11
INSTALLATION 11
SHOCK
DESCRIPTION 12

page

OPERATION 12
DIAGNOSIS AND TESTING - SHOCK ABSORBER 12
REMOVAL 12
INSTALLATION 12
SPRING
DESCRIPTION 13
OPERATION 13
REMOVAL 13
INSTALLATION 13
STABILIZER BAR
DESCRIPTION 14
OPERATION 14
REMOVAL 14
INSTALLATION 14
TRACK BAR
DESCRIPTION 14
OPERATION 14
REMOVAL 14
INSTALLATION 14
UPPER BALL JOINT
REMOVAL 15
UPPER CONTROL ARM
DESCRIPTION 15
OPERATION 15
REMOVAL 15
INSTALLATION 15

FRONT

DESCRIPTION

FRONT SUSPENSION

The front suspension is a link/coil design comprised of:

- Shock absorbers
- Jounce Bumper
- Coil springs
- Upper and lower suspension arms
- Stabilizer bar
- Track bar

CAUTION: Components attached with a nut and cotter pin must be torqued to specification. Then if the slot in the nut does not line up with the cotter pin hole, tighten nut until it is aligned. Never loosen the nut to align the cotter pin hole.

CAUTION: Suspension components with rubber/urethane bushings (except stabilizer bar) should be tightened with the vehicle at normal ride height. It is important to have the springs supporting the weight of the vehicle when the fasteners are torqued. If springs are not at their normal ride position, vehicle ride comfort could be affected and premature bushing wear may occur.

STANDARD PROCEDURE - LUBRICATION

Periodic lubrication of the suspension system is required. Refer to Lubrication And Maintenance for the recommended maintenance schedule.

The following component must be lubricated:

- Track bar