REAR AXLE - 194RBI

TABLE OF CONTENTS

page

REAR AXLE - 194RBI
DIAGNOSIS AND TESTING 84
REMOVAL 88
INSTALLATION 88
ADJUSTMENTS 89
SPECIFICATIONS
REAR AXLE 96
SPECIAL TOOLS 97
AXLE SHAFTS
REMOVAL 100
INSTALLATION 100
AXLE SHAFT SEALS
REMOVAL 100
INSTALLATION 100
AXLE BEARINGS
REMOVAL 101
INSTALLATION 101
PINION SEAL
REMOVAL 101
INSTALLATION 102
COLLAPSIBLE SPACER
REMOVAL 103

page

INSTALLATION 103
DIFFERENTIAL COVER
REMOVAL 105
INSTALLATION 105
DIFFERENTIAL
REMOVAL 105
DISASSEMBLY 106
ASSEMBLY 106
INSTALLATION 107
DIFFERENTIAL - TRAC-LOK
DESCRIPTION 108
OPERATION 108
DIAGNOSIS AND TESTING 108
DISASSEMBLY 109
ASSEMBLY 110
DIFFERENTIAL CASE BEARINGS
REMOVAL 112
INSTALLATION 113
PINION GEAR/RING GEAR
REMOVAL 113
INSTALLATION 115

REAR AXLE - 194RBI

DIAGNOSIS AND TESTING

GEAR NOISE

Axle gear noise can be caused by insufficient lubricant, incorrect backlash, incorrect pinion depth, tooth contact, worn/damaged gears, or the carrier housing not having the proper offset and squareness.

Gear noise usually happens at a specific speed range. The noise can also occur during a specific type of driving condition. These conditions are acceleration, deceleration, coast, or constant load.

When road testing, first warm-up the axle fluid by driving the vehicle at least 5 miles and then accelerate the vehicle to the speed range where the noise is the greatest. Shift out-of-gear and coast through the peak-noise range. If the noise stops or changes greatly:

- Check for insufficient lubricant.
- Incorrect ring gear backlash.
- Gear damage.

Differential side gears and pinions can be checked by turning the vehicle. They usually do not cause noise during straight-ahead driving when the gears are unloaded. The side gears are loaded during vehicle turns. A worn pinion shaft can also cause a snapping or a knocking noise.

BEARING NOISE

The axle shaft, differential and pinion bearings can all produce noise when worn or damaged. Bearing noise can be either a whining, or a growling sound.

Pinion bearings have a constant-pitch noise. This noise changes only with vehicle speed. Pinion bearing noise will be higher pitched because it rotates at a faster rate. Drive the vehicle and load the differential. If bearing noise occurs, the rear pinion bearing is the source of the noise. If the bearing noise is heard during a coast, the front pinion bearing is the source.

Worn or damaged differential bearings usually produce a low pitch noise. Differential bearing noise is similar to pinion bearing noise. The pitch of differential bearing noise is also constant and varies only with vehicle speed.

Axle shaft bearings produce noise and vibration when worn or damaged. The noise generally changes when the bearings are loaded. Road test the vehicle. Turn the vehicle sharply to the left and to the right. This will load the bearings and change the noise