CLUTCH (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
Contact surface of release bearing damaged.	1. Clutch cover incorrect or release fingers bent or distorted.	1. Replace clutch cover and release bearing.
	2. Release bearing defective or damaged.	2. Replace the release bearing.
	3. Release bearing misaligned.	3. Check and correct runout of clutch components. Check front bearing sleeve for damage/ alignment. Repair as necessary.
Partial engagement of clutch disc. One side of disc is worn and the other side is glazed and lightly worn.	1. Clutch pressure plate position incorrect.	1. Replace clutch disc and cover.
	2. Clutch cover, spring, or release fingers bent or distorted.	2. Replace clutch disc and cover.
	3. Clutch disc damaged or distorted.	2. Replace clutch disc.
	4. Clutch misalignment.	4. Check alignment and runout of flywheel, disc, pressure plate, andør clutch housing. Correct as necessary.

SPECIFICATIONS

CLUTCH

TORQUE SPECIFICATIONS

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.
Clutch Cover Bolts - 2.4L	31	23	-
Clutch Cover Bolts - 4.0L	50	37	-
Clutch Cylinder Bolts	23	-	200
Clutch Housing to Engine Bolts	75	55	-
Clutch Housing to Trans Bolts	46	34	-
Dust Shield Bolts	50	37	-
Flywheel Bolts - 2.4L	95	70	-
Flywheel Bolts - 4.0L	142	105	-
Crossmember Frame Bolts	41	30	-