ENGINE

TABLE OF CONTENTS

page

COOLANT
DESCRIPTION
DESCRIPTION - HOAT COOLANT 23
DESCRIPTION - ENGINE COOLANT 24
OPERATION 24
COOLANT RECOVERY CONTAINER
DESCRIPTION 24
OPERATION 25
REMOVAL 25
INSTALLATION 25
ENGINE BLOCK HEATER
DESCRIPTION 25
OPERATION 25
REMOVAL
REMOVAL - 4.0L 26
REMOVAL - 2.4L 26
INSTALLATION
INSTALLATION 4.0L 26
INSTALLATION - 2.4L 26
ENGINE COOLANT TEMPERATURE SENSOR
DESCRIPTION 27
OPERATION 27
REMOVAL 27
INSTALLATION 27
ENGINE COOLANT THERMOSTAT
DESCRIPTION 28
OPERATION 28
REMOVAL
REMOVAL 28
REMOVAL 29
INSTALLATION
INSTALLATION 29
INSTALLATION 29
FAN DRIVE VISCOUS CLUTCH
DESCRIPTION 30
OPERATION 31
DIAGNOSIS AND TESTING
VISCOUS FAN DRIVE 31
REMOVAL 32
INSTALLATION 32
RADIATOR
DESCRIPTION 33

page

OPERATION 33
DIAGNOSIS AND TESTING - RADIATOR
COOLANT FLOW 33
REMOVAL 33
CLEANING 35
INSPECTION 35
INSTALLATION 36
WATER PUMP - 2.4L
DESCRIPTION 36
OPERATION 36
DIAGNOSIS AND TESTING
WATER PUMP 36
REMOVAL - 2.4L 37
INSTALLATION
INSTALLATION 2.4L 37
WATER PUMP - 4.0L
DESCRIPTION 37
OPERATION 38
REMOVAL 38
INSTALLATION 39
RADIATOR PRESSURE CAP
DESCRIPTION 40
OPERATION 40
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - RADIATOR
CAP-TO-FILLER NECK SEAL 41
DIAGNOSIS AND TESTING - RADIATOR
CAP 41
CLEANING 41
INSPECTION 41
RADIATOR FAN
DESCRIPTION 42
REMOVAL
REMOVAL 42
REMOVAL - 4.0L 42
CLEANING 42
INSPECTION 42
INSTALLATION
INSTALLATION 43
INSTALLATION - 4.0L 43
RADIATOR FAN RELAY
DESCRIPTION 43