AUDIO (Continued)

| Audio System Diagnosis | | |
|---|---|---|
| CONDITION | POSSIBLE CAUSE | CORRECTION |
| NO AUDIO. | 1. Fuse inoperative. | 1. Check radio fuse and Ignition-Off Draw fuse in Power Distribution Center. Replace fuses, if required. |
| | 2. Radio connector damaged. | 2. Check for loose or corroded radio connector. Repair, if required. |
| | 3. Wiring damaged. | 3. Check for battery voltage at radio connector. Repair wiring, if required. |
| | 4. Ground damaged. | 4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required. |
| | 5. Radio inoperative. | 5. Exchange or replace radio, if required. |
| | 6. Speakers inoperative. | 6. Refer to speaker diagnosis. |
| NO DISPLAY. | 1. Fuse inoperative. | 1. Check radio fuse and Ignition-Off Draw fuse in Power Distribution Center. Replace fuses, if required. |
| | 2. Radio connector damaged. | 2. Check for loose or corroded radio connector. Repair, if required. |
| | 3. Wiring damaged. | 3. Check for battery voltage at radio connector. Repair wiring, if required. |
| | 4. Ground damaged. | 4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required. |
| | 5. Radio inoperative. | 5. Exchange or replace radio, if required. |
| CLOCK WILL NOT KEEP SET TIME. | 1. Fuse inoperative. | 1. Check ignition-off draw fuse. Replace fuse, if required. |
| | 2. Radio connector damaged. | 2. Check for loose or corroded radio connector. Repair, if required. |
| | 3. Wiring damaged. | 3. Check for battery voltage at radio connector. Repair wiring, if required. |
| | 4. Ground damaged. | 4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required. |
| | 5. Radio inoperative. | 5. Exchange or replace radio, if required. |
| POOR RADIO RECEPTION. | 1. Antenna inoperative. | 1. See antenna diagnosis, in this group. Repair or replace antenna, if required. |
| | 2. Ground damaged. | 2. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required.. |
| | 3. Radio inoperative. | 3. Exchange or replace radio, if required. |
| NO/POOR TAPE OPERATION. | 1. Tape damaged. | 1. Insert known good tape and test operation. |
| | 2. Foreign objects behind tape door. | 2. Remove foreign objects and test operation. |
| | 3. Dirty cassette tape head. | 3. Clean head with Mopar Cassette Head Cleaner. |
| | 4. Radio inoperative | 4. Exchange or replace radio, if required. |