SPEAKER (Continued)



Fig. 5 Instrument Panel Speaker Remove/Install

1 - INSTRUMENT PANEL
2 - SPEAKER
3 - SCREW

INSTALLATION

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, (REFER TO ELECTRICAL/RESTRAINTS) BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

FRONT

(1) Connect the speaker wire connector to the speaker.
(2) Position the speaker to the instrument panel.
(3) Install the four speaker retaining screws. Tighten the screws to 1.1 N·m (10.in.lbs).
(4) Install the speaker bezel to the instrument panel. Tighten the screws to 2.2 N·m (20 in. lbs.).
(5) Connect the battery negative cable.

REAR

(1) Connect wire harness and position speaker into housing.
(2) Install speaker grill and mounting screws.
(3) Connect battery negative cable.