ENGINE SYSTEMS

TABLE OF CONTENTS

page

BATTERY SYSTEM 1
CHARGING 21
STARTING 31

BATTERY SYSTEM

TABLE OF CONTENTS

page

BATTERY SYSTEM
DESCRIPTION 1
OPERATION 2
DIAGNOSIS AND TESTING - BATTERY SYSTEM 2
CLEANING 4
INSPECTION 6
SPECIFICATIONS
BATTERY SYSTEM SPECIFICATIONS 6
SPECIAL TOOLS
BATTERY SYSTEM SPECIAL TOOLS 7
BATTERY
DESCRIPTION 7
OPERATION 8
DIAGNOSIS AND TESTING - BATTERY 8
STANDARD PROCEDURE
STANDARD PROCEDURE - BATTERY CHARGING 8
STANDARD PROCEDURE - BUILT-IN INDICATOR TEST 10
STANDARD PROCEDURE - OPEN-CIRCUIT VOLTAGE TEST 11
STANDARD PROCEDURE - IGNITION-OFF DRAW TEST 11
STANDARD PROCEDURE - USING MICRO 420 BATTERY TESTER 12
REMOVAL 13
INSTALLATION 14
BATTERY HOLDDOWN
DESCRIPTION 14
OPERATION 15
REMOVAL 15
INSTALLATION 15
BATTERY CABLES
DESCRIPTION 16
OPERATION 16
DIAGNOSIS AND TESTING - BATTERY CABLES 16
REMOVAL 18
INSTALLATION 18
BATTERY TRAY
DESCRIPTION 19
OPERATION 19
REMOVAL 20
INSTALLATION 20

BATTERY SYSTEM

DESCRIPTION

A single 12-volt battery is standard factory-installed equipment on this model. All of the components of the battery system are located within the engine compartment of the vehicle. The battery system for this vehicle covers the following related components, which are covered in further detail later in this section of the service manual:

- **Battery** - The storage battery provides a reliable means of storing a renewable source of electrical energy within the vehicle.
- **Battery Cable** - The battery cables connect the battery terminal posts to the vehicle electrical system.
- **Battery Holddown** - The battery holddown hardware secures the battery in the battery tray in the engine compartment.