HEADLAMP
DESCRIPTION 18
OPERATION 18
REMOVAL 18
INSTALLATION 19
ADJUSTMENTS 19
HEADLAMP LEVELING SWITCH
REMOVAL
HEADLAMP LEVELING SWITCH 21
INSTALLATION 21
HEADLAMP LEVELING MOTOR
DIAGNOSIS AND TESTING - HEADLAMP LEVELING SYSTEM 21
LEFT MULTI-FUNCTION SWITCH
DESCRIPTION 23
OPERATION 23
DIAGNOSIS AND TESTING - LEFT MULTI-FUNCTION SWITCH 25
REMOVAL 26
INSTALLATION 27
SIDE MARKER LAMP UNIT
REMOVAL 28
INSTALLATION 28
SIDE MARKER LAMP
REMOVAL 28
INSTALLATION 28
REPEATER LAMP
DESCRIPTION 28
OPERATION 28
DIAGNOSIS AND TESTING - SIDE REPEATER LAMP 28
TAIL LAMP UNIT
DESCRIPTION 29
OPERATION 29
REMOVAL 29
INSTALLATION 29
TAIL LAMP
REMOVAL 30
INSTALLATION 30
TURN SIGNAL CANCEL CAM
DESCRIPTION 30
OPERATION 30
UNDERHOOD LAMP UNIT
REMOVAL 31
INSTALLATION 31
UNDERHOOD LAMP
REMOVAL 31
INSTALLATION 31

LAMPS/LIGHTING - EXTERIOR

DESCRIPTION - TURN SIGNAL & HAZARD WARNING SYSTEM

A turn signal and hazard warning system is standard factory-installed safety equipment. The turn signal and hazard warning system includes the following major components, which are described in further detail elsewhere in this service information:

- **Combination Flasher** - The electronic combination flasher is located on the back of the left multi-function switch, beneath the upper steering column shroud on the top of the steering column.
- **Front Side Marker Lamps** - The front side marker lamps are located on the outboard ends of the two front fender flares.
- **Turn Signal Repeater Lamps** - The turn signal repeater lamps are located on the outboard ends of the two front fender flares.
- **Hazard Warning Switch** - The hazard warning switch is integral to the left multi-function switch. The hazard warning switch button protrudes from an opening in the shroud on the top of the steering column.
- **Turn Signal Cancel Cam** - The turn signal cancel cam is integral to the steering column clockspring, which is located beneath the shrouds on the top of the steering column.
- **Turn Signal Indicators** - The two turn signal indicators are integral to the ElectroMechanical Instrument Cluster (EMIC) located in the instrument panel.
- **Turn Signal Lamps** - The front turn signal lamps are integral to the front park/turn signal lamps located beside each headlamp on the front fender. The rear turn signal lamps are integral to the back-up/brake/rear turn signal/tail lamps located on either side of the rear of the quarter panels.
- **Turn Signal Switch** - The turn signal switch is integral to the left multi-function switch. The left multi-function switch control stalk actuates the turn signal switch in the steering column.

The turn signal system in this vehicle includes a turn signal-on warning chime feature. The EMIC electronic circuitry monitors the turn signal indicators as well as electronic vehicle speed and distance messages received from the PCM over the PCI data bus network to provide this feature. If an indicator remains illuminated continuously with the vehicle speed above about 25 kilometers per hour (15 miles per hour) for a distance of greater than about 1.6 kilometers (1 mile), the EMIC generates a chime through an integral chime tone generator (The distance is greater for export vehicles).

Hard wired circuitry connects the turn signal and hazard warning system components to each other through the electrical system of the vehicle. Refer to the appropriate wiring information.