LAMPS/LIGHTING - EXTERIOR (Continued)

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, DISABLE THE AIRBAG SYSTEM BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE, THEN WAIT TWO MINUTES FOR THE AIRBAG SYSTEM CAPACITOR TO DISCHARGE BEFORE PERFORMING FURTHER DIAGNOSIS OR SERVICE. THIS IS THE ONLY SURE WAY TO DISABLE THE AIRBAG SYSTEM. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

CONDITION	POSSIBLE CAUSES	CORRECTION
ONE TURN SIGNAL LAMP DOES NOT ILLUMINATE	1. Faulty or missing bulb	1. Test and replace turn signal bulb as required.
	2. Faulty ground circuit.	2. Test and repair open ground circuit
	3. Faulty signal circuit.	3. Test and repair open right or left turn signal circuit.
ALL RIGHT SIDE AND/OR LEFT SIDE TURN SIGNAL LAMPS DO NOT FLASH	1. Faulty multifunction switch.	1. Test and replace the multifunction switch as required.
	2. Faulty flasher.	2. Replace the hazard switch/combination flasher.
ALL RIGHT SIDE OR LEFT SIDE TURN SIGNALS FLASH RAPIDLY	1. Faulty or missing bulb.	1. Test and replace faulty bulb as required.
	2. Faulty ground circuit.	2. Test and repair open ground circuit as required.
	3. Faulty signal circuit.	3. Test and repair high resistance or open signal circuit as required.
	4. Faulty flasher.	4. Replace flasher.
HAZARD WARNING LAMPS DO NOT FLASH	1. Faulty or missing fuse.	2. Test and replace fuse as required.
	2. Faulty ground circuit.	2. Test and repair high resistance or open ground circuit.
	3. Open battery positive voltage circuit to hazard warning switch.	3. Test and repair open battery voltage circuit to hazard warning switch.
	4. Faulty flasher	4. Replace flasher
	5. Faulty multifunction switch.	5. Test and replace the multifunction switch as required.

DIAGNOSIS AND TESTING - HEADLAMP SYSTEM

Always begin any diagnosis by testing all of the fuses and circuit breakers in the system. Refer to the appropriate wiring information.