DAYTIME RUNNING LAMP MODULE (Continued)

OPERATION

Battery positive voltage is supplied to the Daytime Running Lamp (DRL) module through a circuit breaker and a fuse in the PDC. Ignition positive voltage is supplied to the DRL module through a fuse in the fuse block. The DRL module also utilizes a Vehicle Speed Sensor (VSS) input, high and low beam sense circuits and high beam indicator driver. The DRL module is grounded to the chassis. Once the vehicle reaches a speed of 3 kph (2 mph) and travels more than 1 meter (3 feet) with the headlamp switch in the off position, the DRL module will activate the HIGH beams at a reduced intensity (36% of full intensity). When the headlamp switch is placed in the LOW beam position the DRL will turn off. When the headlamp switch is turned to the HIGH beam position, the high beams will operate normally (full intensity) and the DRL module will also illuminate the HIGH BEAM indicator in the instrument cluster.

DIAGNOSIS AND TESTING - DAYTIME RUNNING LAMP SYSTEM

Always begin any diagnosis by testing all of the fuses and circuit breakers in the system. Refer to the appropriate wiring information.

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, DISABLE THE AIRBAG SYSTEM BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE, THEN WAIT TWO MINUTES FOR THE AIRBAG SYSTEM CAPACITOR TO DISCHARGE BEFORE PERFORMING FURTHER DIAGNOSIS OR SERVICE. THIS IS THE ONLY SURE WAY TO DISABLE THE AIRBAG SYSTEM. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

CONDITION	POSSIBLE CAUSES	CORRECTION
DAYTIME RUNNING LAMPS (DRL) DO NOT OPERATE	1. Headlamp switch in the on position.	1. Turn the headlamp switch to the off position.
	2. Poor connection at DRL module.	2. Secure connector on DRL module.
	3. Open battery positive voltage circuit to DRL module	3. Test and repair open circuit.
	4. Open ignition positive circuit to DLR module.	4. Test and repair open circuit.
	5. Headlamp circuit shorted to ground.	5. Test and repair headlamp circuit.
	6. Open or high resistance in DLR module ground circuit.	6. Test and repair ground circuit.
	7. Open VSS signal circuit.	7. Test and repair VSS signal circuit.
	8. Defective DRL module.	8. Replace DRL module.

REMOVAL

(1) Disconnect and isolate the battery negative cable.

(2) Disconnect the wire harness connector from the module.

(3) Remove the screws that attach the module to the cowl (Fig. 8).

(4) Separate the module from the vehicle.

INSTALLATION

(1) Position the DRL module on the cowl.

(2) Install the screws.

(3) Connect the wire harness connector to the module.

(4) Connect the battery negative cable.