HEADLAMP LEVELING MOTOR (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ONE MOTOR DOES NOT OPERATE	1. Poor electrical connection at motor.	1. Check for proper electrical harness connection and circuit terminal tension at the motor.
	2. Open or high resistance in the battery positive voltage circuit to the inoperative leveling motor.	2. Repair the open or high resistance in the leveling motor battery positive voltage circuit.
	3. Open, high resistance in the inoperative leveling motor ground circuit.	3. Repair the open, high resistance in the leveling motor ground circuit.
	4. Open, high resistance, short to voltage or short to ground in the inoperative leveling motor sense circuit.	4. Repair the open, high resistance, short to voltage or short to ground in the motor sense circuit.
	5. Inoperative/Damaged motor.	5. Replace leveling motor.
BOTH MOTORS DO NOT OPERATE	1. No battery positive voltage to the headlamp leveling switch.	1. Repair the open circuit or high resistance in the headlamp leveling switch battery positive voltage circuit.
	2. No battery positive voltage to the headlamp leveling motor.	2. Repair the open circuit or high resistance in the headlamp leveling motor battery positive voltage circuit.
	3. Open, high resistance in the headlamp leveling switch ground circuit.	3. Repair the open, high resistance or short to voltage in the headlamp leveling switch ground circuit.
	4. Open, high resistance in the headlamp leveling motor ground circuit.	4. Repair the open, high resistance or short to voltage in the headlamp leveling motor ground circuit.
	5. Open, high resistance, short to voltage or short to ground in the leveling motor sense circuit.	5. Repair the open, high resistance, short to voltage or short to ground in the motor sense circuit.
	6. Inoperative headlamp leveling switch.	6. Replace headlamp leveling switch.
	7. Inoperative headlamp leveling motors.	7. Replace headlamp motors.
MOTORS DO NOT RESPOND TO ONE OR MORE LEVELING POSITION(S)	1. Inoperative headlamp leveling switch.	1. Replace headlamp leveling switch.
	2. Stuck/Binding or Inoperative motor(s).	2. Replace headlamp leveling motor(s).