LEFT MULTI-FUNCTION SWITCH (Continued)

LEFT (LIGHTING) MULTI-FUNCTION SWITCH TEST			
TURN SIGNAL AND HAZARD WARNING SWITCH TESTS			
SWITCH POSITION		CONTINUITY BETWEEN	
TURN	HAZARD		
Neutral	Off	B1 & B4, B1 & B5	
Left	Off	A2 & B2, A2 & B4, B1 & B5	
Right	Off	A2 & B5, B1 & B4	
Neutral	On	A2 & B2, A2 & B4, A2 & B5, A2 & B6, A3 & B7, A3 & A5	
EXTERIOR LIGHTING SWITCH TESTS			
SWITCH POSITION		CONTINUITY BETWEEN	
Park Lamps On		B9 & B20	
Headlamp Low Beams On		B16 & B18, B16 & B19	
Headlamp High Beams On		B17 & B18, B17 & B19	
Fog Lamps On		B13 & B14	
Rear Fog Lamps On		B12 & B13	
Optical Horn On		B17 & B18, B17 & B19	
INTERIOR LIGHTING SWITCH TESTS			
SWITCH POSITION		RESISTANCE BETWEEN	RESISTANCE (OHMS)
Panel Lamps Dimming Position 1 (Dimmest)		B7 & B8	5653 ± 10%
Dimming Position 2		B7 & B8	3743 ± 10%
Dimming Position 3		B7 & B8	2593 ± 10%
Dimming Position 4		B7 & B8	1825 ± 10%
Dimming Position 5		B7 & B8	1221 ± 10%
Dimming Position 6 (Brightest)		B7 & B8	768 ± 10%
Parade Mode On		B7 & B8	412 ± 10%
Courtesy Lamps On		B7 & B8	150 ± 10%

(5) If the left multi-function switch fails any of the continuity or resistance tests, replace the faulty switch unit as required.

REMOVAL

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, DISABLE THE AIRBAG SYSTEM BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL COMPONENT DIAGNOSIS OR SERVICE. DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE, THEN WAIT TWO MINUTES FOR THE AIRBAG SYSTEM CAPACITOR TO DISCHARGE BEFORE PERFORMING FURTHER DIAGNOSIS OR SERVICE. THIS IS THE ONLY SURE WAY TO DISABLE THE AIRBAG SYSTEM. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY.

(1) Disconnect and isolate the battery negative cable.

(2) Remove the steering column opening cover from the instrument panel. (Refer to 23 - BODY/INSTRUMENT PANEL/STEERING COLUMN OPENING COVER - REMOVAL).

(3) Remove the two screws that secure the lower steering column shroud to the upper shroud (Fig. 27).

(4) If the vehicle is equipped with the optional tilt steering column, move the tilt steering column to the fully lowered position and leave the tilt release lever in the released (down) position.

(5) Remove both the upper and lower shrouds from the steering column.

(6) Disconnect the cross body wire harness connector for the left multi-function switch from the connector receptacle on the back of the switch.

(7) Disconnect the cross body wire harness connector for the right multi-function switch from the connector receptacle on the back of the switch.