LAMPS/LIGHTING - INTERIOR

TABLE OF CONTENTS

page

LAMPS/LIGHTING - INTERIOR
SPECIFICATIONS
INTERIOR LAMPS 32
DOME LAMP UNIT
REMOVAL 32
INSTALLATION 32
DOME LAMP
REMOVAL 33
INSTALLATION 33
DOOR AJAR SWITCH
DESCRIPTION 33
OPERATION 34
DIAGNOSIS AND TESTING - DOOR AJAR SWITCH 34
REMOVAL 34
INSTALLATION 34
REAR WIPER/WASHER SWITCH ILLUMINATION LAMP
REMOVAL 35
INSTALLATION 35

LAMPS/LIGHTING - INTERIOR

SPECIFICATIONS

INTERIOR LAMPS

CAUTION: Do not use bulbs that have a higher candle power than the bulb listed in the Bulb Application Table. Damage to lamp housing and lens can result.

Some components have lamps that can only be serviced by an Authorized Service Center (ASC) after the component is removed from the vehicle.

The following table lists the various lamp trade numbers or part numbers.

LAMP	BULB
Dome (Sound Bar)	912
Under Hood	561
Underpanel Courtesy	906
Instrument Cluster Illumination	103
Instrument Cluster Warning	74
Automatic Transmission Indicator	658

DOME LAMP UNIT

REMOVAL

NOTE: The dome lamp removal procedure is the same for both the right and left side dome lamps.

(1) Disconnect the negative battery cable.

NOTE: The dome lamp lens locating tab is larger than the lens retaining tabs.

(2) Insert a small flat blade between the dome lamp housing and dome lamp lens. Carefully pry the lamp lens from the lamp housing (Fig. 1).

(3) Remove the screws that secure the dome lamp housing to the speaker housing.

(4) Remove the dome lamp housing from the speaker housing and disconnect the wire harness connector from the dome lamp.

INSTALLATION

NOTE: The dome lamp installation procedure is the same for both the right and left side dome lamps.

(1) Connect the wire harness connector to the dome lamp.

NOTE: The dome lamp housing is equipped with a locating tab that must be inserted into the slot in the speaker housing.

(2) Align the locating tab with the slot and position the dome lamp housing into the speaker housing (Fig. 2).