WIPERS/WASHERS

TABLE OF CONTENTS

	page		page
FRONT WIPERS/WASHERS	**1**	**REAR WIPERS/WASHERS**	**24**

FRONT WIPERS/WASHERS

TABLE OF CONTENTS

	page		page
FRONT WIPERS/WASHERS		OPERATION	13
DESCRIPTION	1	REMOVAL	13
OPERATION	3	INSTALLATION	14
DIAGNOSIS AND TESTING - FRONT WIPER & WASHER SYSTEM	5	**FRONT WIPER BLADE**	
CLEANING - FRONT WIPER & WASHER SYSTEM	7	DESCRIPTION	14
INSPECTION - FRONT WIPER & WASHER SYSTEM	7	OPERATION	15
FRONT CHECK VALVE		REMOVAL	15
DESCRIPTION	8	INSTALLATION	15
OPERATION	9	**FRONT WIPER MODULE**	
REMOVAL	9	DESCRIPTION	15
INSTALLATION	10	OPERATION	16
FRONT WASHER HOSES/TUBES		REMOVAL	16
DESCRIPTION	10	DISASSEMBLY	17
OPERATION	10	ASSEMBLY	17
FRONT WASHER NOZZLE		INSTALLATION	17
DESCRIPTION	10	**RIGHT MULTI-FUNCTION SWITCH**	
OPERATION	11	DESCRIPTION	18
REMOVAL	11	OPERATION	19
INSTALLATION	11	DIAGNOSIS AND TESTING - RIGHT MULTI-FUNCTION SWITCH	19
FRONT WASHER PUMP MOTOR		REMOVAL	20
DESCRIPTION	11	INSTALLATION	21
OPERATION	12	**WASHER RESERVOIR**	
REMOVAL	12	DESCRIPTION	22
INSTALLATION	13	OPERATION	22
FRONT WIPER ARM		REMOVAL	22
DESCRIPTION	13	INSTALLATION	23

FRONT WIPERS/WASHERS

DESCRIPTION

An electrically operated intermittent front wiper and washer system is standard factory-installed safety equipment on this model (Fig. 1). The front wiper and washer system includes the following major components, which are described in further detail elsewhere in this service information:

- **Front Check Valve** - The front washer system check valve is located in the washer plumbing on the underside of the hood panel between the cowl and the front washer nozzle.