WIRING

TABLE OF CONTENTS

page

WIRING DIAGRAM INFORMATION 8W-01-1
COMPONENT INDEX 8W-02-1
POWER DISTRIBUTION 8W-10-1
FUSE BLOCK 8W-11-1
GROUND DISTRIBUTION 8W-15-1
BUS COMMUNICATIONS 8W-18-1
CHARGING SYSTEM 8W-20-1
STARTING SYSTEM 8W-21-1
FUEL/IGNITION SYSTEM 8W-30-1
TRANSMISSION CONTROL SYSTEM 8W-31-1
VEHICLE SPEED CONTROL 8W-33-1
ANTILOCK BRAKES 8W-35-1
VEHICLE THEFT SECURITY SYSTEM 8W-39-1
INSTRUMENT CLUSTER 8W-40-1
HORN/CIGAR LIGHTER/POWER OUTLET .. 8W-41-1

page

AIR CONDITIONING-HEATER 8W-42-1
AIRBAG SYSTEM 8W-43-1
INTERIOR LIGHTING 8W-44-1
AUDIO SYSTEM 8W-47-1
REAR WINDOW DEFOGGER 8W-48-1
FRONT LIGHTING 8W-50-1
REAR LIGHTING 8W-51-1
TURN SIGNALS 8W-52-1
WIPERS 8W-53-1
SPLICE INFORMATION 8W-70-1
CONNECTOR PIN-OUTS 8W-80-1
CONNECTOR/GROUND/SPLICE LOCATION 8W-91-1
POWER DISTRIBUTION 8W-97-1