# 8W-10 POWER DISTRIBUTION


| Component | Page |
|---|---|
| A/C Compressor Clutch | 8W-10-16 |
| A/C Compressor Clutch Relay | 8W-10-16 |
| Automatic Shut Down Relay | 8W-10-13 |
| Axle Lock Switch | 8W-10-17 |
| Battery | 8W-10-9 |
| Battery Temperature Sensor | 8W-10-13 |
| Blower Motor Relay | 8W-10-9 |
| Circuit Breaker | 8W-10-10 |
| Coil Capacitor | 8W-10-14, 15 |
| Compass/Temperature Mirror | 8W-10-17 |
| Controller Antilock Brake | 8W-10-10 |
| Data Link Connector | 8W-10-17 |
| Engine Starter Motor | 8W-10-9, 12 |
| Engine Starter Motor Relay | 8W-10-12 |
| Fog Lamp Relay | 8W-10-16 |
| Front Locker Pump | 8W-10-19 |
| Front Locker Relay | 8W-10-19 |
| Fuel Injector No. 1 | 8W-10-14, 15 |
| Fuel Injector No. 2 | 8W-10-14, 15 |
| Fuel Injector No. 3 | 8W-10-14, 15 |
| Fuel Injector No. 4 | 8W-10-14, 15 |
| Fuel Injector No. 5 | 8W-10-14 |
| Fuel Injector No. 6 | 8W-10-14 |
| Fuel Pump Module | 8W-10-16 |
| Fuel Pump Relay | 8W-10-16 |
| Fuse 1 | 8W-10-9, 10 |
| Fuse 2 | 8W-10-9, 10 |
| Fuse 3 | 8W-10-10 |
| Fuse 4 | 8W-10-10 |
| Fuse 5 | 8W-10-12, 18 |
| Fuse 6 | 8W-10-12 |
| Fuse 7 | 8W-10-12 |
| Fuse 8 | 8W-10-10, 12 |
| Fuse 9 | 8W-10-11, 13 |
| Fuse 10 | 8W-10-10, 11 |
| Fuse 11 | 8W-10-11 |
| Fuse 12 | 8W-10-10, 11 |
| Fuse 13 | 8W-10-11 |
| Fuse 14 | 8W-10-11 |
| Fuse 15 | 8W-10-9, 17 |
| Fuse 17 | 8W-10-11, 18 |
| Fuse 18 | 8W-10-11, 16 |
| Fuse 19 | 8W-10-16 |
| Fuse 20 | 8W-10-18 |
| Fuse 21 | 8W-10-16 |
| Fuse 22 | 8W-10-11 |
| Fuse 23 | 8W-10-16 |
| Fuse 24 | 8W-10-19 |
| Fuse 26 | 8W-10-17 |
| Fuse 27 | 8W-10-18 |
| Fuse 28 | 8W-10-13 |
| Fuse Block | 8W-10-9, 10, 11, 12 |
| Fusible Link | 8W-10-9 |
| G106 | 8W-10-9 |
| G107 | 8W-10-9 |
| G108 | 8W-10-9 |
| G300 | 8W-10-11 |
| Generator | 8W-10-9 |
| High Speed Radiator Fan Relay | 8W-10-10 |
| Horn | 8W-10-16 |
| Horn Relay | 8W-10-16 |
| Ignition Coil Pack | 8W-10-14, 15 |
| Ignition Switch | 8W-10-11, 12 |
| Instrument Cluster | 8W-10-11, 17 |
| Left Courtesy Lamp | 8W-10-17 |
| Left Dome Lamp | 8W-10-17 |
| Left Fog Lamp | 8W-10-16 |
| Low Speed Radiator Fan Relay | 8W-10-10 |
| Multi-Function Switch | 8W-10-16, 18 |
| Power Distribution Center | 8W-10-2, 9, 10, 11, 12, 13, 16, 17, 18, 19 |
| Power Outlet | 8W-10-18 |
| Powertrain Control Module | 8W-10-12, 13, 18 |
| Radio | 8W-10-18 |
| Rear Locker Pump | 8W-10-19 |
| Rear Locker Relay | 8W-10-19 |
| Rear Window Defogger | 8W-10-9 |
| Rear Window Defogger Relay | 8W-10-9 |
| Right Courtesy Lamp | 8W-10-17 |
| Right Dome Lamp | 8W-10-17 |
| Right Fog Lamp | 8W-10-16 |
| Transmission Control Relay | 8W-10-18 |
| Transmission Solenoid/Pressure Switch Assembly | 8W-10-18 |
| Underhood Lamp | 8W-10-17 |
| Variable Line Pressure Sensor | 8W-10-18 |