FUEL PUMP RELAY

CAVITY	CIRCUIT	FUNCTION
C6	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C7	-	-
C8	K31 20BR	FUEL PUMP RELAY CONTROL
C9	A109 18OR/RD	FUEL PUMP RELAY OUTPUT
C10	A930 18RD	FUSED B(+)

HIGH SPEED RADIATOR FAN RELAY (2.4L)

CAVITY	CIRCUIT	FUNCTION
D10	A16 12GY	FUSED B(+)
D11	N112 20DB/OR	HIGH SPEED RADIATOR FAN RELAY CONTROL
D13	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D14	C25 12YL	HIGH SPEED RADIATOR RELAY OUTPUT

HORN RELAY

CAVITY	CIRCUIT	FUNCTION
C11	A43 18RD/DG	FUSED B(+)
C12	-	-
C13	X3 20RD/YL	HORN RELAY CONTROL
C14	X2 18DG/OR	HORN RELAY OUTPUT
C15	A43 18RD/DG	FUSED B(+)

LOW SPEED RADIATOR FAN RELAY (2.4L)

CAVITY	CIRCUIT	FUNCTION
D2	A16 12GY	FUSED B(+)
D4	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D6	N201 20DB/LG	LOW SPEED RADIATOR FAN RELAY CONTROL
D8	C23 12DG	LOW SPEED FAN RELAY OUTPUT