8W-31 TRANSMISSION CONTROL SYSTEM

Component	Page
Axle Lock Switch	8W-31-13, 14
Brake Lamp Switch	8W-31-2
Brake Transmission Shift Interlock Solenoid	8W-31-2
Clutch Pedal Position Switch	8W-31-9
Data Link Connector	8W-31-9
Fog Lamp Relay	8W-31-3
Front Locker Indicator Switch	8W-31-12
Front Locker Pump	8W-31-11
Front Locker Relay	8W-31-11
Fuse 5	8W-31-3
Fuse 7	8W-31-7
Fuse 10	8W-31-2
Fuse 24	8W-31-11
Fuse Block	8W-31-2, 7
G100	8W-31-3
G105	8W-31-2, 3, 11, 12
G200	8W-31-10, 14
G300	8W-31-2
Input Speed Sensor	8W-31-9
Instrument Cluster	8W-31-2, 10, 12, 13, 14
Left Rear Lamp Assembly	8W-31-7
Output Speed Sensor	8W-31-9
Power Distribution Center	8W-31-3, 11
Powertrain Control Module	8W-31-2, 3, 4, 5, 6, 8, 9, 10, 14
Rear Locker Indicator Switch	8W-31-12
Rear Locker Pump	8W-31-11
Rear Locker Relay	8W-31-11
Right Rear Lamp Assembly	8W-31-7
Tow/Haul Overdrive Off Switch	8W-31-10
Transfer Case Switch	8W-31-2, 14
Transmission Control Relay	8W-31-3, 4, 5
Transmission Range Sensor	8W-31-6, 7, 9
Transmission Solenoid/Pressure Switch Assembly	8W-31-4, 5
Variable Line Pressure Sensor	8W-31-8