8W-80 CONNECTOR PIN-OUTS

Component	Page
A/C Compressor Clutch	8W-80-3
A/C High Pressure Switch (4.0L)	8W-80-3
A/C Low Pressure Switch	8W-80-3
A/C Pressure Transducer (2.4L)	8W-80-3
A/C-Heater Control C1 (Except Heater Only)	8W-80-3
A/C-Heater Control C2 (Except Heater Only)	8W-80-4
A/C-Heater Control C3 (Except Heater Only)	8W-80-4
Airbag Control Module	8W-80-4
Ambient Temperature Sensor (Compass/ Temperature Mirror)	8W-80-5
Ambient Temperature Sensor (Engine)	8W-80-5
Axle Lock Switch (Off-Road Package)	8W-80-5
Back-Up Lamp Switch (M/T)	8W-80-5
Battery Temperature Sensor	8W-80-6
Blend Door Actuator	8W-80-6
Blower Motor	8W-80-6
Blower Motor Relay	8W-80-6
Blower Motor Resistor Block	8W-80-7
Brake Lamp Switch	8W-80-7
Brake Transmission Shift Interlock Solenoid	8W-80-7
Brake Warning Indicator Switch	8W-80-7
C102	8W-80-8
C102	8W-80-8
C103	8W-80-9
C103	8W-80-9
C104 (RHD)	8W-80-10
C104 (RHD)	8W-80-10
C109 (A/T)	8W-80-10
C109 (A/T)	8W-80-11
C170	8W-80-11
C170	8W-80-12
C181 (2.4L)	8W-80-12
C181 (2.4L)	8W-80-13
C182 (2.4L)	8W-80-13
C182 (2.4L)	8W-80-14
C203	8W-80-14
C203	8W-80-14
C205	8W-80-15
C205	8W-80-15
C300	8W-80-16
C300	8W-80-17
C301	8W-80-18
C301	8W-80-19
C324	8W-80-20
C324	8W-80-20
C325	8W-80-20
C325	8W-80-20
C326 (Hard Top)	8W-80-20
C326 (Hard Top)	8W-80-21
C329 (Export)	8W-80-21
C329 (Export)	8W-80-21
Camshaft Position Sensor	8W-80-21
Cigar Lighter/Power Outlet	8W-80-22
Circuit Breaker	8W-80-22
Clockspring C1	8W-80-22
Clockspring C2	8W-80-22
Clutch Pedal Position Switch (M/T)	8W-80-22
Coil Capacitor	8W-80-23
Compass/Temperature Mirror	8W-80-23
Controller Antilock Brake	8W-80-23
Crankshaft Position Sensor	8W-80-24
Data Link Connector	8W-80-24
Daytime Running Lamp Module (Except Export)	8W-80-24
Driver Airbag Squib 1	8W-80-25
Driver Door Ajar Switch	8W-80-25
Engine Coolant Temperature Sensor	8W-80-25
Engine Oil Pressure Switch	8W-80-25
EVAP/Purge Solenoid	8W-80-25
Front Locker Indicator Switch (Off-Road Package)	8W-80-26
Front Locker Pump (Off-Road Package)	8W-80-26
Front Washer Pump	8W-80-26
Front Wiper Motor	8W-80-26
Fuel Injector No. 1 (2.4L)	8W-80-27
Fuel Injector No. 1 (4.0L)	8W-80-27
Fuel Injector No. 2 (2.4L)	8W-80-27
Fuel Injector No. 2 (4.0L)	8W-80-27
Fuel Injector No. 3 (2.4L)	8W-80-27
Fuel Injector No. 3 (4.0L)	8W-80-28
Fuel Injector No. 4 (2.4L)	8W-80-28
Fuel Injector No. 4 (4.0L)	8W-80-28
Fuel Injector No. 5 (4.0L)	8W-80-28
Fuel Injector No. 6 (4.0L)	8W-80-28
Fuel Pump Module	8W-80-29
G-Switch	8W-80-29
Generator	8W-80-29
Headlamp Leveling Switch (Export)	8W-80-29
Heater Control C1 (Heater Only)	8W-80-29
Heater Control C2 (Heater Only)	8W-80-30
Heater Control C3 (Heater Only)	8W-80-30
Horn	8W-80-30
Idle Air Control Motor	8W-80-30
Ignition Coil Pack (2.4L)	8W-80-30
Ignition Coil Pack (4.0L)	8W-80-31
Ignition Switch	8W-80-31
Input Speed Sensor	8W-80-31
Instrument Cluster C1	8W-80-31
Instrument Cluster C2	8W-80-32
Intake Air Temperature Sensor (4.0L)	8W-80-32