CONNECTOR/GROUND/SPLICE LOCATION (Continued)

Connector Name/Number	Color	Location	Fig.
C103	BK	Rear of Engine Compartment	10, 12, 17, 18
C104	BK	Rear of Engine Compartment	17, 18
C109 (A/T)	LT-GY	Rear of Engine Compartment	10, 12, 17, 18
C170 (LHD)	WT	Left Kick Panel	24
C170 (RHD)	WT	Right Kick Panel	27
C180	BK	Below Evap/Purge Solenoid	N/S
C181	BK	Left Rear of Engine Head	4
C182	BK	Left Rear of Engine Head	4
C203 (LHD)	GN	Left Kick Panel	26
C203 (RHD)	GN	Right Kick Panel	29
C205	LT GN	Left Kick Panel	25, 27
C300 (LHD)	GY	Left Kick Panel	22, 24, 38
C300 (RHD	GY	Right Kick Panel	23, 27
C301 (LHD)	YL	Left Kick Panel	22, 38
C301 (RHD)	YL	Right Kick Panel, see LHD Similar	23
C324 (Speaker Pod)	WT/BK	Right Side of Sport Bar	N/S
C325 (Speaker Pod)	WT/BK	Left Side of Sport Bar	38, 39
C326 (Hard Top)	BK	Left Rear Quarter Panel	38, 39
C329 (Export)	BK	Left Rear of Rear Bumper	41
Camshaft Position Sensor (4.0L)	BK	Right Side of Engine	7
Camshaft Position Sensor (2.4L)	BK	Right Front Corner of Engine Head, behind Air Cleaner	N/S
Center High Mounted Stop Lamp	BK	Near Right Rear Lamp Assembly	41, 42
Cigar Lighter/Power Outlet	RD	Rear of Cigar Lighter	26, 28
Circuit Breaker	GY	Near Day Time Running Lamp Module	19, 21
Clockspring - C1	NAT	Rear of Clockspring	30
Clockspring - C2	YL	Rear of Clockspring	30
Clutch Pedal Position Switch (M/T)	BK	Top of Clutch Pedal Bracket	21, 22
Coil Capacitor (2.4L)		Rear Engine	4, 17
Coil Capacitor (4.0L)	BK	Right Rear of Engine Head	7
Compass/Temperature Mirror	BK	At Top Center of Windshield	N/S
Controller Anti-Lock Brake	BK	Rear Left Side of Dash Panel	12, 14
Crankshaft Position Sensor (4.0L)	BK	At Rear of Intake Manifold	7
Crankshaft Position Sensor (2.4L)	BK	Left Bellhousing	4
Data Link Connector	BK	Bottom Driver Side of Instrument Panel	24, 27
Daytime Running Lamp Module (Except Export)	BK	Left Side of Engine Compartment	10
Driver Airbag Squib	YL	Under Horn Pad	31
Driver Door Ajar Switch	NAT	At ″A″ Pillar	22, 23