CONNECTOR/GROUND/SPLICE LOCATION (Continued)

Connector Name/Number	Color	Location	Fig.
Left Front Position Lamp (Export)	BK	At Lamp	1
Left Front Speaker	BK	At Speaker	24, 27
Left Front Turn Signal Lamp (Export)	BK	At Lamp, See Right	2
Left Front Wheel Speed Sensor	BK	Left Side of Engine Compartment Near Hydraulic Control Unit	13, 14
Left Headlamp	BK	Rear of Lamp	1
Left Headlamp Leveling Motor (Export)	BK	Near Headlamp at Motor	1
Left License Lamp (Export)	GY	At Lamp	41, 42
Left Rear Lamp Assembly	BK	At Lamp	41, 42
Left Rear Speaker	BK	In Left Speaker/lamp Pod	N/S
Left Rear Wheel Speed Sensor	BK	Near Vehicle Speed Sensor T/O	16, 40
Left Side Marker Lamp	GY	At Lamp, See Right	2
Left Side Repeater Lamp (Export)	GY	At Lamp, See Right	2
Left Speed Control Switch		Left Steering Wheel	31
Manifold Absolute Pressure Sensor	BK	Side of Throttle Body	4, 5
Multi-Function Switch C1	GY	Steering Column	30
Multi-Function Switch C2	BK	Steering Column	30
Natural Vacuum Leak Detection Assembly	BK	Under Rear Body	41, 42
Output Speed Sensor	BK	Rear Left Side of Trans	16, 36
Oxygen Sensor 1/1 Upstream		On Front Exhaust Pipe	5, 17
Oxygen Sensor 1/2 Downstream	BK	Rear of Catalytic Converter	5, 36, 37
Oxygen Sensor 2/1 Upstream (4.0L California/European III)		Near Idle Air Control Motor T/O	5
Oxygen Sensor 2/2 Downstream (4.0L California/ European III)	GY	T/O near Ignition Coil Pack T/O	5, 35
Park Brake Switch		Left of Seat Belt Switch	20
Passenger Airbag	YL	Rear of Airbag	19, 21
Passenger Airbag On/Off Switch		Lower Center of Instrument Panel	26
Passenger Door Ajar Switch	BK	Near Top Hinge of Passenger Door	19, 21
Power Distribution Center	BK	Engine Compartment Right or Left Fenter	13
Power Distribution Center Eyelet	N/A	Engine Compartment Right or Left Fenter	11
Power Outlet		Center of Instrument Panel	26, 28
Power Steering Pressure Switch (2.4L)	BK	Near Power Steering Pump	4