CONNECTOR/GROUND/SPLICE LOCATION (Continued)

Connector Name/Number	Color	Location	Fig.
Right Headlamp	BK	Rear of Lamp	2
Right Headlamp Leveling Motor (Export)	BK	Near Headlamp at Motor	2
Right License Lamp	GY	At Lamp	41, 42
Right Rear Lamp Assembly	BK	At Lamp	41, 42
Right Rear Speaker	BK	In Right Speaker/lamp Pod	N/S
Right Rear Wheel Speed Sensor	BK	Near Vehicle Speed Sensor T/O	16, 40
Right Side Marker Lamp (Except Export)	GY	At Lamp	2
Right Side Repeater Lamp	GY	At Lamp	2
Right Speed Control Switch	BK	Right Steering Wheel	31
Seat Belt Switch	BK	Near Park Brake Switch	20
Sentry Key Immobilizer Module	BK	At Immobilizer	30
Speed Control Servo	BK	Left Side Engine Compartment	13, 14
Subwoofer	LT-GY	Floor Pan	20
Throttle Position Sensor	WT	Side of Throttle Body	5, 18
Tow/Haul Overdrive Off Switch		Center of Instrument Panel	26, 28
Transfer Case Switch	BK	Left Side of Transfer Case	16, 36, 37
Transmission Range Indicator Illumination (PRNDL)	BK	Between Seats	20
Transmission Range Sensor	GN	Left Center of Transmission	16, 36
Transmission Solensid/ Pressure Switch Assembly	NAT	Right Center of Transmission	7, 36
Underhood Lamp	BK	Under Hood	10, 12, 18
Variable Line Pressure Sensor		Left Side of Transmission	16, 36
Vehicle Speed Sensor	BK	Left Rear of Transfer Case	16, 36, 37