ROCKER ARMS
REMOVAL 32
INSPECTION 33
INSTALLATION 33
ENGINE BLOCK
DESCRIPTION 33
STANDARD PROCEDURE
PISTON TO CYLINDER BORE FITTING 33
CYLINDER BORE HONING 34
CLEANING 34
INSPECTION 34
CONNECTING ROD BEARINGS
STANDARD PROCEDURE
CONNECTING ROD - FITTING 35
CRANKSHAFT
DESCRIPTION 36
OPERATION 36
STANDARD PROCEDURE - CRANKSHAFT
END PLAY 36
REMOVAL 36
INSPECTION 37
INSTALLATION 37
CRANKSHAFT MAIN BEARINGS
STANDARD PROCEDURE - MAIN BEARING -
FITTING 39
CRANKSHAFT OIL SEAL - FRONT
REMOVAL 40
INSTALLATION 41
CRANKSHAFT OIL SEAL - REAR
REMOVAL 42
INSTALLATION 42
PISTON & CONNECTING ROD
DESCRIPTION 43
OPERATION 43
REMOVAL 43
INSTALLATION 44
PISTON RINGS
STANDARD PROCEDURE
PISTON RING - FITTING 45
VIBRATION DAMPER
REMOVAL 47
INSTALLATION 47
STRUCTURAL COLLAR
REMOVAL 47
INSTALLATION 47
ENGINE MOUNTING
DESCRIPTION 47
FRONT MOUNT
REMOVAL 48
INSTALLATION 48
REAR MOUNT
REMOVAL 49
INSTALLATION 49
LUBRICATION
DESCRIPTION 49
OPERATION 49
DIAGNOSIS AND TESTING
ENGINE OIL PRESSURE CHECKING 50
OIL
STANDARD PROCEDURE
ENGINE OIL LEVEL CHECK 50
ENGINE OIL AND FILTER CHANGE 50
OIL FILTER
DESCRIPTION 51
REMOVAL 51
INSTALLATION 51
OIL PAN
REMOVAL 51
INSTALLATION 52
OIL PRESSURE SENSOR/SWITCH
DESCRIPTION 52
OPERATION 52
OIL PUMP
REMOVAL 52
DISASSEMBLY 53
CLEANING 53
INSPECTION 53
ASSEMBLY 54
INSTALLATION 54
INTAKE MANIFOLD
DESCRIPTION 55
OPERATION 55
DIAGNOSIS AND TESTING
INTAKE MANIFOLD LEAKS 55
REMOVAL 55
INSPECTION 56
INSTALLATION 56
EXHAUST MANIFOLD
DESCRIPTION 56
OPERATION 56
REMOVAL 56
CLEANING 57
INSPECTION 57
INSTALLATION 57
TIMING BELT COVER(S)
REMOVAL 57
INSTALLATION 57
TIMING BELT AND SPROCKET(S)
REMOVAL
TIMING BELT 58
CRANKSHAFT SPROCKET 59
CLEANING 59
INSTALLATION
CRANKSHAFT SPROCKET 59
TIMING BELT 60
TIMING BELT TENSIONER & PULLEY
REMOVAL 62
INSTALLATION 62
BALANCE SHAFTS AND CARRIER ASSEMBLY
DESCRIPTION 63
OPERATION 63
REMOVAL 63
INSTALLATION 65