OIL PUMP (Continued)




*Fig. 84 Crankshaft Key*

1 - CRANKSHAFT KEY




*Fig. 85 2.4L OIL PUMP*

1 - BOLTS
2 - BOLTS

## DISASSEMBLY

(1) To remove the relief valve, proceed as follows:
(a) Remove the threaded plug and gasket from the oil pump.
(b) Remove spring and relief valve.
(2) Remove oil pump cover fasteners, and lift off cover.
(3) Remove pump rotors.
(4) Wash all parts in a suitable solvent and inspect carefully for damage or wear.

## CLEANING

(1) Clean all parts thoroughly in a suitable solvent.

## INSPECTION

(1) Inspect the mating surface of the oil pump. Surface should be smooth. Replace pump cover if scratched or grooved.
(2) Lay a straightedge across the pump cover surface (Fig. 86). If a 0.025 mm (0.001 in.) feeler gauge can be inserted between cover and straight edge, cover should be replaced.
(3) Measure thickness and diameter of outer rotor. If outer rotor thickness measures 9.40 mm (0.370 in.) or less (Fig. 87), or if the diameter is 79.95 mm (3.148 in.) or less, replace outer rotor.




*Fig. 86 Checking Oil Pump Cover Flatness*

1 - STRAIGHT EDGE
2 - FEELER GAUGE
3 - OIL PUMP COVER




*Fig. 87 Measuring Outer Rotor Thickness*