INTAKE MANIFOLD (Continued)

CAUTION: Cover intake manifold openings to prevent foreign material from entering engine.

(16) Inspect the manifold. (Refer to 9 - ENGINE/MANIFOLDS/INTAKE MANIFOLD - INSPECTION)

INSPECTION

(1) Check manifold surfaces for flatness with straight edge. Surface must be flat within 0.15 mm per 300 mm (0.006 in. per foot) of manifold length.

(2) Inspect manifold for cracks or distortion. Replace manifold if necessary.

INSTALLATION

(1) Clean manifold sealing surfaces.

(2) Install new manifold to cylinder head seals.

(3) Install manifold to head.

(4) Install and tighten intake manifold fasteners to 28 N·m (250 in. lbs.) in the sequence shown (Fig. 92). Repeat procedure until all bolts are at specified torque.



80e371a2

Fig. 92 LOWER INTAKE MANIFOLD TIGHTENING SEQUENCE

(5) Install throttle cables in bracket.

(6) Connect throttle, speed control, (if equipped), cables to throttle lever.

(7) Connect vacuum lines for power brake booster, LDP, EGR transducer, and speed control vacuum reservoir (if equipped) at upper intake manifold fittings.

(8) Connect vacuum lines for purge solenoid and PCV valve.

(9) Connect electrical connectors for MAP sensor, throttle position sensor (TPS), and idle air control (IAC) motor.

(10) Connect the fuel line. (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/QUICK CONNECT FITTING - STANDARD PROCEDURE)

(11) Connect coolant temperature sensor/fuel injector wiring harness electrical connector.

(12) Install the air cleaner housing and air intake tube to throttle body.

(13) Connect inlet air temperature sensor connector.

(14) Connect negative cable to battery.

EXHAUST MANIFOLD

DESCRIPTION

The exhaust manifold is made of Hi-Silicone Moly nodular cast iron for strength and high temperatures. The manifold attaches to the cylinder head.

OPERATION

The exhaust manifold collects the exhaust gasses exiting the combustion chambers. Then it channels the exhaust gasses to the exhaust pipe attached to the manifold.

REMOVAL

(1) Raise vehicle and disconnect exhaust pipe from the exhaust manifold.

(2) Lower the vehicle.

(3) Disconnect upstream oxygen sensor connector at the rear of exhaust manifold.

(4) Remove the air cleaner bracket (Fig. 93).



80e483e8

Fig. 93 AIR CLEANER BRACKET

1 - AIR CLEANER BRACKET
2 - BOLT (2)